



## **ID Mobile 2000 User Manual**

iDTRONIC GmbH  
Donnersbergweg 1  
67059 Ludwigshafen  
Germany/Deutschland

Issue 4.4  
– 15. May 2019 –

Phone: +49 621 6690094-0  
Fax: +49 621 6690094-9  
E-Mail: [info@idtronic.de](mailto:info@idtronic.de)  
Web: [idtronic.de](http://idtronic.de)

Subject to alteration without prior notice.  
© Copyright iDTRONIC GmbH 2018  
Printed in Germany

## Contents

<b>1</b>	<b>Keybutton instruction .....</b>	<b>4</b>
<b>2</b>	<b>Install SIM card, TF card.....</b>	<b>5</b>
<b>3</b>	<b>Buttons guide .....</b>	<b>6</b>
<b>3.1</b>	<b>Status Icon.....</b>	<b>6</b>
<b>4</b>	<b>Using the notification .....</b>	<b>7</b>
<b>5</b>	<b>Management of device.....</b>	<b>7</b>
<b>6</b>	<b>Barcode reader function.....</b>	<b>9</b>
<b>7</b>	<b>Maintenance and Layup .....</b>	<b>10</b>

# 1 Keybutton instruction

**1.Power:** Long time to push the Power button to turn-on/ off device.

In any interface, press power button one second into lock and unlock interface. Press 10seconds power button will be reset smart phone

**2.Volume button:**


When you're listening to songs, movies, or other media, the vol buttons on the side of phone could be adjust the audio volume up or down. If has the lowest volume, press the volume down.

Tip: Vibration/Silent switch

Please hold the power button then touch the Vibration or Silent mode. Also could be set by Touch application icon->setting->Device->Sound & notification

**3.Barcode reader button:**

There are 2 barcode reader buttons on the two side of the device which color is orange. Pushing Barcode reader button 3seconds the barcode reader function will be turn on, Pushing the barcode reader button in to scanning by short second. (noted: before scanning you should open a dialog box and put it in the typing status, the reader information will show in the dialog box. Please reference the pictures as follows)



**4.Touch buttons (from left to right)**

**Menu:** open interface of menu current

**Home screen:** back to home screen, long time to push the home screen into last application.

**Return Back:** back to last interface or exit the currently program.

**5. Physics button (from left to right)**

**F1:** Long time to press or shortly press could open pre-install program. If you want change the pre—install program, please in to the setting→keyEvent→physics button F1 to set.

**F2:** Long time to press or shortly press could open pre-install program. If you want change the pr—install program, please in to the setting→keyEvent→physics button F2 to set.

**Physics home screen button:** Shortly pushing in to home screen directly

**Fingerprint:** its could be unlock the device, or wake up the locked interface. Setting→ suggestions→screen lock

First time setting the finger print, the system might prompting your setting the device by fingerprint and pattern together. If you choosed this one, you will need imputing the fingerprint and pattern together to unlock the device when you reboot the device. if not, just imput the fingerprint or pattern is fine.

## 2 Install SIM card, TF card


Please turn off device before you install the SIM cards or TF card

1.Please find the screwdriver in the giftbox and use it open the battery cover, take out the battery, according the remindful to put the SIM cards.

2. Both SIM card slots support 4G LTE.



**Please turn off the device before you take out the SIM cards or TF card**

3 Buttons guide



3.1 Status Icon

	E: GSM 3G: WCDMA 4G: 4G LTE		Notification
	Call forwarding		Play music
	Miss calling		Connected WLAN
	New SMS or MMS		Calling out
	Alarm Clock		Airplane mode
	Vibration mode		Silent
	Bluetooth		Battery capacity
	Connect to PC		Barcode reader on


	Connected earphone		Charging
---	--------------------	---	----------

## 4 Using the notification

Notification will include new message, Calendar events or ongoing events, such as in caller diverting or in calling status. You could also open notification to check phone operator or open message, reminder or events notification. When there is a new notification. Belowing operation could be done after you slider it down to open the notification

\*Tab the notification to open relating app.

\*Tab and press the bottom then slide up to shut down the notification.

**Note:** When in standby screen, you could tab  this icon to open the notification, entering quick open or shut down relating app, also could do quick operation to Wi-Fi, bluetooth, off-line mode etc.

### Using APP icon

APP icon contains all the applications on your phone. Tabbing it to open. Tab return icon on the bottom of the screen to return to homepage.

### Recently been used APPS

Long press the home screen button to view recently been used APPS, such as Photos, Album, setting etc, drag corresponding apps up or down it could delete the trace.

### Recently application

Long time to push home screen button in to check used application recently, might it browser, settings, message, gallery etc. please drag the application from left or right will be clear the application trace.

### Expand the homepage

Main interface to go beyond the screen width for more spaces in which new shortcuts, widgets and more other items can be added. In addition, users can horizontally swipe their fingers at the homepage screen to move to the left or right of the expanded the homepage interface.

1. in standby mode, long pressing the blank part of the display to enter settings of homepage interface.
2. choosing widgets, add whichever one you want to show in the homepage, it will automatically in the blank space of homepage.
3. in homepage interface, tab and pin any app icon, to drag it to the blank space of homepage.

### Move homepage interface icons:

1. Tabbing and pin the icon till the icon become bigger.
2. Stay still of your finger and drag the icon to the place where you want it to be on the homepage.

### Remove homepage interface icons.

1. Tabbing and pin the icon till the icon become bigger.
2. Stay still of your finger, drag the icon till it become red, then leave your finger.
3. When all the icons and widgets in the homepage been deleted, this homepage will be deleted automatically.

## 5 Management of device

Please go to settings menu to set your device.

### Wireless and network

#### Management of SIM:

Setting SIM1 or SIM 2 card turn on/off which in the menu settings→SIM cards. It will show airplane mode icon on the status bar after you turn off the SIM card.

#### Setting cellular date turn on/off.

Settings-》SIM cards-》preferred sim for

#### SIM cards application

Please find the SIM toolkit menu in the main system to understand more information

#### Wi-Fi

Settings→Wi-Fi-》turn on-> choose the Wi-Fi name and input the password to connected Wi-Fi

#### Bluetooth

Settings→Bluetooth→turn on →choose the one of available devices to pair.

**More:**

**Airplane mode:** there is no any service after you turn on the function.

**VPN:** VPN network.

**Network sharing & portable hotspots:** Allow the equipment of wireless network without through wireless router connected to each other (Wi-Fi hotspots); Share your mobile connection via USB (USB sharing network) ; Choose to share or not share computer internet connection.

**Mobile network:** Check data usage, open or close 4G/3G service, change network mode, access point name, select a network provider in operators.

**Device**

**Display:** Setting device display brightness, wallpaper, Auto Rotate Screen, sleeping mode, body size and other display function.

**Cue tone & notice:** Set voice volume and ring setup.

**Storage:** Check SD card and relevant display information of mobile phone, can download or format SD card.

**Battery:** Show the usage of battery capacity.

**Application:** Manage and delete installed applications. Check and control storage usage of running service and apps.

**User:** Set main and visitor pattern.

**Touch payment:** Support touch payment function.

**Gesture:** Support gloves functions, double click to wake up under standby condition, support gesture to open camera and torch function. Under the condition of opening gesture, it will automatically switch to normal touch mode if there is no any operation within 15 seconds, please switch back on gloves function if needed.

**Person**

**Location information:** Set relevant functions about my location.

**Security**

**Screen lock:** Use picture, PIN or password to lock screen.

**Device manager:** Manage relevant devices.

**Unknown sources:** Setting if allowed to download application from non-electric market.

When your setting is allowed, your phone and personal data will be easy to be attacked by applications of unknown sources, you will be responsible for the loss because of these applications.

**Trusted Credentials:** Allows the application to access security credentials and other credential.

**Storage and install from mobile phone:** After clicked, you will Install storage encryption certificates from mobile.

**Clear credentials:** Clear all the credential store content.

**Account**

**Add account:** You can add accounts, add the required account; Through the full synchronization, set all current account into sync. Conventional synchronous Settings to set the background data, automatic synchronization.

**Back up and reset:** Through the factory default, remove all the data on the phone. Remove data including: account, system and application data and Settings, download should be: select the appropriate language, setting the keyboard and select the default input method.

The application does not delete data including the current system software, SD Calvin parts, such as music or photos.

**System**

**Date and time:** setting Automatic date & time, Automatic time zone, Use 24-hour format.

**Accessibility:** Adjust miscellaneous function

**Print:** Can be printed after installation service

**About Phone:** Can be checked Status, Legal information, Model Number, Processor information, android version, Energy version, Kernel version, Build Number



## 6 Barcode reader function

Please open a dialog box which could input in message then into setting→Scanner


### 4.USB connection

#### USB charging


There is default charging function when you connect the device with your computer.

#### How to copy your file or pictures from device to your computer?

Please connect the device with your computer by type-C cable then slip the touch screen from top to low -side then you will see the information as follow pictures.



Please click the “USB for file transfer” you will get the follow picture:



Choosing transfer files then you will find the file or pictures in your computer.

## 7 Maintenance and Layup

### User's Manual for Battery

The rechargeable battery may serve as power source of the mobile phone. Please charge the battery when it becomes low in electricity. It is recommended to use up the battery capacity before charging for the sake of longer battery life.

Please do not attach the battery charger to any power supply if the charger is not in service. Never attach the charger to the battery for over one week as excessive charging will shorten the battery life.

Temperature will challenge chargeable limit of the battery, so the battery may need to be cooled down or warmed up prior to charging. Charging will fail if the battery temperature is above 55°C or below -20°C.

Please only use the battery for its originally-designed purpose to avoid short circuit. Short circuit will occur if the cathode and anode of the battery are connected via a conductor.

Never use the battery if it has become damaged.

The battery life will become shortened if the battery is placed in any extremely-hot or extremely-cold environment. The mobile phone may not function properly if the battery is exposed to any extremely-hot or extremely-cold environment even if the battery is fully charged.

Do not put the battery in fire. Do not throw away any used batteries. Used batteries shall be sent to battery recycling services and disposed in accordance with local regulations.

### Mobile Phone Layup

The following recommendations will be conducive to layup of your mobile phone:

Please place the mobile phone and all accessories at any place away from children.

Please keep the phone dry as liquid will corrode metallic circuit.

Please keep the phone away from high temperature as high temperature will shorten life of electronics, melt plastics and damage the battery.

Do not attempt to open the phone case or disassemble the phone. Non-professional dis-assembly will potentially damage the phone.

Do not use any detergent containing strong acid or base to clean the phone.

Always use original accessories, violation of which will void its warranty.

### Safety Information

Always observe safety regulations for protecting users and environment when using the mobile phone.

#### Traffic Safety

Unless in emergency, please do not use the mobile phone while driving if no hands-free devices for safety and free movement are attached. Make sure that you are fully concentrated to driving. Please pull up your car to a safe place before you use the phone. Related regulations must be observed.

Some electronics may be affected by radio waves from transmitted by your mobile phone if no sufficient protection is made available.

It is recommended to use the mobile phone only in vehicles with external antenna.

Always have qualified technicians install the mobile phone onto your vehicle.

#### Flight Safety

Please switch off your mobile phone before boarding as mobile phones will challenge operation of aircraft and entire cellular network. It is illegal to use mobile phones on the plane and violation of these safety regulations will be accused or result in network denial-of-service.

#### Environmental Safety

Keep in mind to observe existing particular rules and policies at any places. Always remember to switch off your mobile phone where use of mobile phone is prohibited or may result in interference or danger.

Use of any wireless transmitting equipment, including cellular phone, might interfere with medical device not properly protected. Please ask doctor or medical device manufacturer for advice should you have any questions in this respect.

Your mobile phone might interfere with hearing aids, pacemaker and other medical electronics. Please follow suggestions from doctor or the manufacturer.

Users are recommended to switch off their mobile phones at any places where explosion may occur, e.g. gas station and chemical plants. Observe related restrictions on use of wireless devices.

### System Update Security

The mobile phone is typically subject to authorized operating system update.

Any unauthorized operating system update might result in failure of updated operating system to comply with security requirements for mobile intelligent terminals, with system information security loophole.

## 8 Technical specifications

<b>Waterproof</b>	IP67
<b>Shockproof</b>	MIL-STD-810G
<b>ATEX</b>	Optional, battery capacity is 3650mAh
<b>Operation</b>	Android 7.0
<b>Display</b>	5.0inch IPS 1280*720 Dragontrial/AGC
<b>Camera</b>	Rear 8.0MP
<b>CPU</b>	Octa-core MT6753
<b>Storage</b>	ROM+RAM:16GB+2GB
<b>GSM</b>	B5/850;B8/900;B3/1800;B2/1900
<b>3G</b>	WCDMA B1/2100;B2/1900;B5/850;B8/900; CDMA2000/EVDO 3G:TD/SCDMA
<b>4G LTE</b>	FDD-LTE: B1/2100;B3/1800;B7/2600;B20/800; TDD-LTE: B38/B39/B40/B41
<b>Sim Card</b>	Dual sim card,Dual standby
<b>WiFi</b>	dual Wi-Fi 2.4/5GHz A/B/G/N/
<b>Navigation</b>	GPS,BEIDOU, GLONASS
<b>Fingerprint</b>	Support
<b>2D Scanner SE4710(MOTO)</b>	UPC/EAN, Bookland EAN ,UCC Coupon Code,ISSN EAN,Code 128,GS1-128,ISBT 128,Code 39,Trioptic Code 39 ,Code 32,Code 93 ,Code 11,PDF417, MicroPDF417, Composite, RSS, TLC-39, Datamatrix, QR code, Micro QR code, Aztec, MaxiCode, Postal Codes, US PostNet, US Planet, UK Postal, Australian Postal, Japan Postal, Dutch Postal. etc.
<b>NFC NXP548 CHIP</b>	Support 14443A Topza, 14443A MIFARE UL, JIS 6319-4 Sony Felica,14443A/B NXP DES Fire etc